

REX BOGUE

"THE BALZ" Instructions for Installation

There are essentially two ways to wire the "BALZ". One with conventional tone controls, and one with active treble boost and cut, (which is recommended). The volume (100K) is placed between the blue wire and the output jack. The orange and yellow wires determine gain by a resistor placed across them and also work with the tone circuit. In a guitar where "THE BALZ" won't fit without routing, with the battery attached, attach a 9 volt battery clip to "THE BALZ" and one to the battery itself. You can now separate the battery and locate it by itself. Observe polarity.

